

Merlin+ Instructions

MT/MR Series Motors

1. Press and hold the button on the new remote you wish to program to the door.
2. Press and release the orange or purple LEARN button which is located on the motor. This is generally found at the back of the motor or under the light cover.
3. The motor light will flash once to indicate the remote has been programmed.
4. Release all buttons and test the new remote.

WARNING!

This product may contain a coin/button cell battery. Keep product and batteries away from children. Battery can cause severe or fatal injuries in 2 hours or less if swallowed or placed inside any part of the body. Seek immediate medical attention if it is suspected that a coin/button battery has been swallowed or placed inside of any part of the body.

