

Smart Instructions

1. Locate the Code Button on the motor panel.
2. Press the Code Button for 2 seconds and then release. The screen on the motor will display code learn.
3. Press the same button on the new remote twice.
4. Test the new remote.
5. Repeat steps 1-4 if you'd like to program additional remotes.

WARNING!

This product may contain a coin/button cell battery. Keep product and batteries away from children. Battery can cause severe or fatal injuries in 2 hours or less if swallowed or placed inside any part of the body. Seek immediate medical attention if it is suspected that a coin/button battery has been swallowed or placed inside of any part of the body.

