

Herculift Instructions

1. Locate the 'Control Panel' on the garage motor. This will be a series of buttons usually located under the light cover of the motor.
2. Remove the light cover to access the buttons.
3. Press and release the button labelled 'Learn'. A red light should illuminate.
4. Press the button twice on the new remote you wish to operate your door.
5. Your new remote is now programmed once the red light on the motor stops flashing.

WARNING!

This product may contain a coin/button cell battery. Keep product and batteries away from children. Battery can cause severe or fatal injuries in 2 hours or less if swallowed or placed inside any part of the body. Seek immediate medical attention if it is suspected that a coin/button battery has been swallowed or placed inside of any part of the body.

